



Installation Instructions

1. Hold the PlantBox panel in the location you require and mark the position against the wall.



2. Use a spirit level to ensure that the panel is at a fixed level. Remove the top trough.



3. Drill in to the wall using either M10 coach bolts / wall anchors or similar fixings.



4. Re-insert top trough.



5. The PlantBox troughs are now ready to be planted! Fill the base of each trough with the recommended free-draining substrate.



6. Remove the plant from its pot.



7. After loosening any tight roots, insert the plant in to the trough. Repeat steps 6-7.



8. Fill between the plants with substrate and compact. Make sure the substrate reaches into the corners.



General Notes:

- Fill the troughs half way with substrate (growing medium) and lightly compact.
- Take each of your plants out of their pot and place into the trough on the substrate.
- Make sure the top of the root ball is level or just below the top of the trough edge.
- The plants can then be rearranged to form the design or pattern of your choice.
- TIP: It is best to space two plants between each trough divider
- Once you are happy with the design proceed to plant fully.
- Part the substrate and firm the plant into it.
- TIP: It is easier to plant into moist substrate, so add water to the substrate before planting.
- Compact the substrate round the root ball of the plant.
- Top up the substrate to the top of the panel and compact. Make sure that the substrate is pushed in to all four corners.
- Repeat steps 5-8 until your wall is complete.
- Present the foliage to the front of the panel.
- Water in the plants.
- TIP: Make sure the irrigation lines are inserted before planting up your panels.